

EH-VS EDGE

Recessed LED panel

LED |



Installation Instructions

Technical data:

- Input: 220-240Vac 50-60Hz.
- IP20
- Electrical protection class: Class II



For illustration only

Disconnect mains power before installation.



Important:

This light fixture is classified as electrical & electronic waste (WEEE). Once ceased operation It is mandatory to destroy it according to your local waste directives.


Warning:


1. Connecting this light fixture to mains will be conducted only by qualified and licensed electrician. It is mandatory to disconnect mains supply prior to installation or service.
2. Replace any broken protective cover.
3. This light fixture is designed for indoor installation, according to listed IP level.
4. The usage of non-complying dimming devices for low voltage systems may damage the power supply device.
5. The light fixture must not be covered by any isolation material.
6. For type Y attachment:
If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
7. For non-user replacement light sources:
"The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person".

Maintenance:


1. Use only a soft antistatic wipe to clean the diffuser.
2. In case of a fault, do not try to fix it on your own. Uninstall the light fixture and contact your nearest official service station.
3. To not use Alcohol, detergents, chemical and such to clean the light fixture.
4. The light unit source is non-replaceable.

Electrical wiring scheme:





1. This luminaire is designed for recessed installation on gypsum, metal or wood ceilings.
2. Cut open a hole in your ceiling fitting the luminaires dimensions according to the specific model.
3. Insert the luminaire into the open cut, bending the support springs to the upper position prior the inserting. Once inserted, the springs will hold the luminaire into place.
4. Do not cover the luminaire by any insulating material.
5. Connect the light fixture to the power supply, according to the wiring scheme.
6. Set requested CCT level on CCT Dip switch.
7. Light fixture is ready for operation.



Warranty is valid according to the enlisted data on our website, and/or as listed on client quotation. by our local representative.